



Handle Wire Change

This is a very hard job that is best carried out by an experienced service centre and we can only offer you tips and advice on how to change the handle wire.

- ✓ Open the handle on your trolley and disconnect the handle wires from the Potentiometer (Pot)
- ✓ Un plug the two white connector blocks, this is located underneath your trolley
- ✓ The white male connector block that comes out of the tube (not the controller) needs to be cut with a pair of scissors.
- ✓ Now loosen/remove all of the grommets to ease the pulling of the new cable.
- ✓ Put one grommet (GSP100430) on to the new handle wire and tape the new handle wire to the existing one, this should enable you to pull the new handle wire through.
- ✓ As you pull through from the base, section at a time, make sure you add grommets or re use the old ones.
- ✓ If you have difficulties, spray the cable with silicone spray to reduce friction.

GolfStream International Limited, Lakesview Business Park, Canterbury, Kent. CT3 4JH

Telephone: 01227 713173

Fax: 01227 719884

E-Mail: sales@golfstream.co.uk

Website: www.golfstream.co.uk