



In order to change the standard Potentiometer on your Original Classic trolley you will need to carry out the following instructions.

Equipment Needed: A small selection of Spanners, 11mm-13mm (depends on age of machine), flat headed screw driver.

1. Undo all the screws on the top of the handle and separate the top and bottom halves.
2. The black knob on the side of the handle needs to be removed, the green cap needs to come off first. This is quite simple and a flat headed screwdriver can be used to ease it off, be careful not to slip!
3. With the correct spanner undo the brass/silver nut that you have now revealed. This only needs to be undone slightly so that the knob slides off.
4. You will then see another nut, with the 13 mm spanner remove this and the barbed washer, retain these for use later.
5. Coming up through the handle tube will be a handle wire, with three wires. You will need to undo the connector so that the red, blue and green wires are released from the block connector.
6. The Potentiometer will now be able to be fully removed from the handle.
7. The new Pot is ready to fit.
8. In order to fit the Pot you will need to put the largest barbed washer on first, then fit the Pot through the hole in the handle. The smaller barbed washer then goes on followed by the nut. Tighten the nut with the spanner but do not over tighten the nut, as soon as you feel a resistance it is the perfect time to stop tightening.
9. Turn the shaft of the pot towards you (anticlockwise) until it stops, put the black knob onto the shaft of the Pot, please make sure that the white line on the knob is facing up. Tighten the brass nut inside the knob this should be tight enough so that it turns the Pot and but will not turn on the shaft of the Pot.
10. Replace the green cap
11. You now need to connect the wires back into the connector block, blue to blue, green to green and red to brown. Once you have inserted the wire please tighten. Nearly finished but before we close the handle ensure that the wires are tight, to do this just tug on the wire. If any wiring comes out of the connector then you have not done it tight enough.
12. Tuck all the wires into the inner handle
13. This is the final bit, put all the screws back in to the top of the handle and do the handle up ensuring that you do not catch any of the wires.
14. Test your machine.

GolfStream International Limited, Lakesview Business Park, Canterbury, Kent. CT3 4JH

Telephone: 01227 713173

Fax: 01227 719884

E-Mail: sales@golfstream.co.uk

Website: www.golfstream.co.uk