



## Fitting Instructions for Compact Plus style controller

This is not a simple job as it is a bit fiddly, be prepared to be dextrous and patient!

- At the rear of the battery tray, disconnect the handle cable and motor cables and unhitch them from the cable retainers.
- Remove the sticky label from the front of the battery tray.
- Undo the two screws either side of the heat sink and retain.
- Carefully ease out the heat sink, this will start to pull the cables through from the back of the tray.
- Note that the motor leads go to the left, the battery cable in the centre and the handle cable to the right. You may need to help the battery connector through as this is tight.
- Pull gently until the controller is released.
- Offer up the new controller so that the Blue cable is to the left.
- Thread in the handle cable to the right, the motor cables to the left and the battery connector in the middle, again, you will have to help the battery connector through.
- Now gradually and carefully pull the cables through from the back of the tray so that the printed circuit board fits into the aperture, you will need to make sure that the cables are not in the way of the relay (black box) as it is a tight fit along the bottom edge.
- Once fitted into the outer lip, fit the two retaining screws.
- Now refit the motor wires and fit the wires behind the wire retaining clip, now do the same with the handle cable.
- Now fit your battery and check the machine works well.
- If all is well, apply the protective sticker over the silver plate. If all is not well, check your connections and that the battery has a charge, then call us.

**GolfStream Limited**, Lakesview Business Park, Canterbury, Kent. CT3 4JH

Telephone: 01227 713173

Fax: 01227 719884

E-Mail: [sales@golfstream.co.uk](mailto:sales@golfstream.co.uk)

Website: [www.golfstream.co.uk](http://www.golfstream.co.uk)