



## Hill Billy Style Clutch

Equipment Needed:- None

In order to change the clutch on your existing Hill Billy Golf Trolley, you will need to follow the following instructions

1. Remove the main wheel from the existing clutch
2. To remove the clutch will require you to pull the clutch of the existing roll pin, this may be tough and we would recommend using an old cloth to avoid damaging your hands
3. Push the new clutch on to the roll pin and replace the main wheel

**GolfStream International Limited, Lakesview Business Park, Canterbury, Kent. CT3 4JH**

Telephone: 01227 713173

Fax: 01227 719884

E-Mail: [sales@golfstream.co.uk](mailto:sales@golfstream.co.uk)

Website: [www.golfstream.co.uk](http://www.golfstream.co.uk)